



Play Command



Main: *'Label or place to come back to can be any single word*
sleep 1 *'Low power sleep delay to save power approx 1 to 65 seconds*
play 1, 3 *'Play preset tune number 1 with LED flash code 3*
goto Main *'Go back to the start again*



- The first digit selects the 4 preset tunes (0, 1, 2, and 3) Try them out
- The second digit is the LED code option (0, 1, 2 or 3) that selects the one or both or no LED's flashing alternately in time to the music on pins 0 and 4
- You can write your own music using the Tune command
- Look up the Play and Tune commands under Help in Manual II for more options
- The picaxe M2 series chips can use a different music output pin port number