



Tune Command



Main: *'Label or place to come back to can be any single word*
Sleep 1 *'Low power sleep delay to save power approx (1 to 65 seconds)*
Tune 3, 5, (1,2,3,4,3,2,1) *'Flash LED code 3 while playing a tune from pin2 at Tempo 5*
goto Main *'Go back to the start again*



- A musical tune editor is accessed from Menu PICAXE > Wizards > Ring Tone Tune
- As above numbers can be entered directly into the brackets for a quicker results
- LED flash code options 0,1,2 or 3 are the same as the Play command. Experiment !
- Look up the Tune and Play command under Help in Manual II for more options
- Picaxe M2 chips allow use of different output pins for the music. Refer to Manula II in the Help section